

**NO NEED TO SET
ZERO BEFORE USE**

- No need to set zero before use
- Suitable for small spaces like crankshaft
- Longitudinal and transverse V-grooves on bottom for shafts (shafts dia. 19.3~115.9mm)
- With transverse vial

| Code | Length | Sensitivity |
|---------|--------|--------------------|
| 4907-90 | 90mm | 0.1mm/m (=0.0057°) |



4907-90

SHORT LEVEL

INSIZE PLUS

MADE IN GERMANY

