



Digital Car Battery Tester BT-330



Features

Tests the output voltage of a charger dynamo and checks the accidental short circuitry in wirings
Portable, no power required
charging system min voltage :13.7V

Temperature Compensation:

Batterytemp	+20°F	0°F	-20°F
Decreasebat ratingby	1 step	2 step	3 step

Loadvoltage	Minvoltage
10.2V	7.7V
10.4V	8.2V
10.6V	8.7V
10.8V	9.2V
11.0V	9.7V
11.2V	10.2V
11.4V	10.6V